

MAPEI ADHESIVE RECOMMENDATION FOR EGGER

Flooring installation

Flooring	Adhesives	Trowel	Consumption	Time for light foot traffic
EGGER Aqua+ Laminate	ULTRABOND ECO S968 1K	TKB B11	approx. 1.000 g/m ²	24 hours
EGGER Design GreenTec	ULTRABOND ECO S968 1K	TKB B3	approx. 800 g/m ²	24 hours

Substrate preparation

Waterproofing barrier, if required*	MAPEGUARD WP 200 + MAPEGUARD WP ADHESIVE				
Levelling compound	ULTRAPLAN XTRA	ULTRAPLAN XTRA	PLANITEX FAST	ULTRAPLAN XTRA	PLANITEX FAST
Primer	PRIMER MF EC PLUS	ECO PRIM T PLUS 1:3 diluted with water	ECO PRIM T PLUS 1:2 diluted with water	ECO PRIM GRIP PLUS	ECO PRIM T PLUS 1:1 diluted with water
Mechanical preparation	e.g. clean, abrase, vacuum, depending on the substrate				
Substrate	Concrete	Cement screed	Calciumsulphate screed	Existing ceramic tiles	Asphalt screed

* We recommend to consult the MAPEI Technical Assistance.

This recommendation contains products that are sold in Germany. For other products, please contact the local MAPEI subsidiary; contacts available at www.mapei.com.

The mentioned products describe the application in an abbreviated form. Please note the corresponding Technical Data Sheets.